

Manually set the Day/Night mode: System Ring Plans

Press the Night button, enter the ring plan passcode (0000) and the ring plan (1-Night, 2- Day) you wish to set. The system will override all the automatic time tables and will remain in the set ring plan until manually changed. To manually change or cancel the ring plan time override and return ring plan operation to the automatic system schedule: Press the Night button plus the ring plan passcode (0000) and “0” to cancel the ring plan time override and return to normal operation.

- Press Night button
- Enter passcode 0000
- Enter plan number – (1 – Night, 2 – Day)

******* Note *******

When returning the system back to original scheduled time:

- **Press Night button**
- **Enter passcode 0000**
- **Enter plan number 0**